

Syncra SDC PSK SDC

PUMP CONFIGURATION

Other languages available on
www.sicce.com > products > aquariums and accessories > Syncra SDC

CONTRALL

FREE DOWNLOAD

Available on the
App Store

ANDROID APP ON
Google play



SICCE CLOUD

sicce.zepping.it

Use your ContrALL account
to log in.



STEP 1

**Download CONTRALL App
in your smartphone.**

**Create your account in the
APP.**

Do not use any symbols like: "/(=&

STEP 2

**Connect the CONTROLLER to
the power adapter.**

The Controller will be flashing and this is
normal (all LED ON).

After some minutes the
CONTROLLER creates
a WIFI network called
"SICCE(***)"**

STEP 3



In your smartphone's **SETTINGS**, select **Wi-Fi**.

SICCE controllers are compatible with WiFi 2.4Ghz networks. Please check this detail before proceeding.

STEP 4



Select **SDC pump's network**.

If the network doesn't appear, wait for 30 seconds then repeat the network search.

STEP 5



Write the password:
sicceitaly

STEP 6



Connect.

STEP 7



Press on the network
once it is connected.


iOS



STEP 8.A

With **iOS** Press on “Configure WiFi”
when the screen appears.

Android



STEP 8.B


With **Android** you should click
the link of the IP address.

If not allowed
copy the IP address
and paste it in the URL bar
of your browser (Chrome, etc.)



STEP 9.A

Select **The WiFi Network of the place where you are** (home, office, shop, hotel, etc.)



STEP 10.A

Type the **password** related to it..


iOS

Android



STEP 9.B

Press on **“Configure WiFi”** when the screen appears.



STEP 10.B

Select **The WiFi Network of the place where you are** (home, office, shop, hotel, etc.)




STEP 11.A

Insert your **APP ContrALL login & password** (you have set your account the first time you opened ContrALL App).

Give a **name** to your SDC pump (for example "My pump 1").

Press "SAVE".




STEP 12.A

If you see this screen, **wait** few seconds.


iOS

Android



STEP 11.B

Type the **password** related to it..



STEP 12.B

Insert your **APP ContrALL login & password** (you have set your account the first time you opened ContrALL App).

Give a **name** to your SDC pump (for example "My pump 1").

Press "SAVE".

